



REMOTE CONTROLS

SECURE AND RELIABLE HOME ACCESS

**AUTOMATIC TECHNOLOGY
REMOTE CONTROLS MAKE
COMING AND GOING FROM
HOME A BREEZE.**

Our patented remote control technology delivers reliable and secure access control. Our 128-bit encryption avoids interference from wireless devices within your home and prevents code grabbing.

TrioCode™ 128 Remote Controls:



Premium 4 Button



Standard 4 Button



Water Resistant 2 Button

AT A GLANCE:



GARAGE AND GATE CONTROL

Each button can control a different door or gate allowing control of multiple access points to your home.

BEWARE OF IMITATIONS

Only genuine Automatic Technology remote controls feature TrioCode™ 128 encryption.

OPTIONS TO SUIT YOUR LIFESTYLE

With options of 2 or 4 buttons and available in standard and premium designs, choose the remote right for you.

REMOTE CONTROLS

WITH PATENTED TRIOCODE™ 128 TECHNOLOGY



Premium 4 Button
PTX6v1 #61228 Black

\$



Premium 4 Button
PTX6v1 #61229 Grey

\$



Water Resistant 2 Button
PTX2v2 #61169

\$




Standard 4 Button
PTX5v2 #61159

\$



PTX6 Visor Clip Pack
#61402

\$



PTX5 Visor Clip Pack
#61457

\$



Standalone Receiver
1 Channel #14800

\$



Standalone Receiver
2 Channel #14805

\$



Plug in Receiver
2 Channel #14810

\$



Plug in Receiver
Kit #14815

\$

HOW TO CODE A TRIOCODE™128 REMOTE TO YOUR AUTOMATIC TECHNOLOGY

GARAGE DOOR OPENER

The opener can only operate from remote controls that have been programmed into its receiver.

To program the remote control into the opener follow the steps below:

1. Ensure the power to the opener is on and the controls lid cover is removed.
2. Press and hold the DOOR CODE button on the opener (do not release).
3. Press and hold the remote control button that you want to control the door for 2 seconds and release.
4. Press and hold the same remote control button for another 2 seconds; release. Release the DOOR CODE button.
5. The remote control is now coded to the opener - press the coded button to test.

Note: if the DOOR CODE button is released during this process repeat steps 2 - 4 again.

GATE OPENER

1. Select MENU 1 "code transmitter".
2. Press SET, the controller will prompt to press one of the remote control button.
3. Press the remote button you wish to use to operate the opener for 2 seconds and release.
4. Press the same remote control button again as prompted by the display for 2 seconds.
5. Press EXIT or STOP button to exit MENU.



View **How To** video

UPGRADE YOUR OLD REMOTE

Whilst the original Triocode™ has proven to be safe, this level of security has been superseded by TrioCode™128.

Triocode™128 remote controls can be used:

- As a replacement for a PTX5 remote with orange button.
- With a receiver to operate any brand of garage door or gate openers.



www.automatictechnology.com.au

SMART
SIMPLE 
SECURE